

## Carbon Dioxide (CO<sub>2</sub>)



Carbon Dioxide extinguishers are mainly used to cover electrical risks and also can extinguish smaller flammable liquid fires. The gas is clean and common places for use include computer server rooms and offices. Jewel Fire Group Carbon Dioxide extinguishers are assembled in the UK and we supply the 2Kg with a frost-free safe horn and the 5Kg with hose and horn as standard.

### Key Benefits

- 10 year warranty from date of manufacture
- Aluminium cylinders – lighter than steel equivalent and lower risk of corrosion
- 2Kg and 5Kg versions Marine Equipment Directive Approved recycling capability
- Refunds for return of cylinders at end of life (see Cash for Cans)
- Boxed for safe transportation
- Recycling Capability



Horn Detail

Hanging Bracket

Code	2CX	5CX
Capacity	2Kg	5Kg
Fire Rating	34B	55B
Charged Weight	4.8Kg	10.8Kg
Operating Pressure	55 BAR	55 BAR
Height Of Ext.	517mm	670mm
Diameter	104mm	152mm
Width Of Ext.	180mm	200mm
Discharge time	10s	15s
Discharge Distance	4-5m	4-5m