



# IntelliCare™ Hybrid Dispenser

Smarter Design. Sustainable Care.

## A complete and intelligent hand care solution

The IntelliCare™ Hand Hygiene dispensing system is part of a complete and intelligent hand care solution designed to prevent infection, improve productivity and protect your brand reputation.

The IntelliCare™ Hybrid touchless hand care dispenser is the first one worldwide to include patented hybrid technology, enabling always-available hand hygiene. The dispensing system addresses all of your hand care needs with a versatile, modern and durable platform that is compatible with liquid, cream and foam products.

## Dispenser Features

- Patented hybrid functionality
- Low-content alert informs staff when product level is low, enabling a “never empty” function
- Robust and reliable ABS-plastic, scratch and UV-resistant body with no dirt traps make for an easy maintenance and spotless appearance
- Leading battery life and waterproof components to ensure reliable long-lasting operations with minimal maintenance requirements
- State-of-the-art dispenser design with a large window, allowing user content visibility and product identification from outside
- Simple and intuitive touch-free operation, complimented by an illuminated “Push” icon if batteries need replacing
- Dose size switch within the dispenser
- Snap-in, customizable placard and window labels for product identification, messaging and color coding
- Accessories that enable hand hygiene across application areas: drip tray and floorstand.

## Benefits

- Always-available functionality minimizes the risk of HCAs and other “never events” resulting from non-operational dispensers
- Improved work efficiencies with a quick and easy dispensing, refill and product identification
- Innovative functionality and infection-prevention features improve customer experience
- Smooth and safe user experience stimulates hand hygiene compliance and positive public health
- Kind to the environment, with an unparalleled lifecycle sustainability assessment
- Modern design allows for a smooth set-up and natural blend-in across usage environments





# IntelliCare™ Hybrid Dispenser

Smarter Design. Sustainable Care.

## Refill Bottle Features

- Fully collapsible recyclable bottle that uses up to 30% less plastic/ml than conventional bottles
- Hermetically sealed bottle with no-drip/no-clog dosing pump that ensures content is free from contamination, avoiding the risk of bacterial build-up
- Larger volume bottle that provides cost-effective hand hygiene and minimizes number of refill changes
- Key-necked plug-in bottle, for a quick, safe and easy refill process
- Unique bottle design collapsing from the back to enable full product visibility, with a <50 doses cue that informs when bottle will soon need replacing, enabling full product evacuation.

## Use Instructions

- Place palms approximately 5 cm below dispenser
- Product will be dispensed within 1 second of sensor activation
- If "PUSH" symbol is lit, use manual push pad to dispense product

Technical data	
Color	Black/White
Output	0.4mL/push 1.0mL/push
Dimensions (cm.)	28.2 (H) x 15.8 (W) x 10.1 (D)
Material	ABS (body) PP (backplate) Polyoxymethylene (hammer) polycarbonate (window)
Battery lifetime	90.000 activations* <small>*Based on normal use with liquid at low dose</small>

Description/Package Size	Product Code
IntelliCare Hybrid Dispenser, Black 1pc	D7524179
IntelliCare Hybrid Dispenser, White 1pc	D7524180
IntelliCare Drip Tray, Black 1pc	D7524181
IntelliCare Drip Tray, Grey 1pc	D7524182
IntelliCare Floorstand, 1pc	D1224249

To download users' guide and for additional information, please visit: [www.diversey.com/intellicare](http://www.diversey.com/intellicare)

## Medguard Professional Healthcare

Tel: 01 835 2378

Email: [orders@medguard.ie](mailto:orders@medguard.ie)

Fax: 01 969 5009

Web: [www.medguard.ie](http://www.medguard.ie)

Unit 6/7, Block 4, Ashbourne Business Park, Ashbourne, Co. Meath, Ireland