



# IntelliCare™ Hand Hygiene Dispenser

## Manual Handcare Dispenser

The IntelliCare™ Hand Hygiene dispensing system can address all of your hand care needs with a versatile, modern and durable platform that is compatible with liquid/gel and foam products.

### Features & Benefits

- State-of-the-art dispenser design with a large site window allows user content visibility without opening the dispenser
- Ability to convert from keyed to keyless gives you the flexibility to choose your dispenser security levels
- Ultimate versatility is achieved with one system that will dispense both liquid and foam products
- Robust and reliable ABS-plastic, scratch and UV-resistant body with no dirt traps make for an easy maintenance and spotless appearance
- Dose size adjuster allows you to vary the volume of soap dispensed based on end user needs
- ADA and CCD compliant to meet all of your facilities needs

### Applications

- Great for use in areas where frequent hand washing or sanitizing requires an always-available product dispensing option





# IntelliCare™ Hand Hygiene Dispenser

Manual Handcare Dispenser

## Use instructions



- Place hand underneath dispenser
- Push pad to dispense product into hands

## Refill Bottle Features

- Fully collapsible recyclable bottle that uses up to 30% less plastic/ml than conventional bottles
- Hermetically sealed bottle with no-drip/no-clog dosing pump that ensures content is free from contamination, avoiding the risk of bacterial build-up
- Larger volume bottle that provides cost-effective hand hygiene and minimizes number of refill changes
- Key-necked plug-in bottle, for a quick, safe and easy refill process
- Unique bottle design collapsing from the back to enable full product visibility, with a <50 doses cue that informs when bottle will soon need replacing

Technical data	IntelliCare Manual Dispenser
ADA/CCD Compliant	Yes
Color	Black/White
Output	0.4 mL/push, 1.0 mL/push
Dimensions	10.24"(H) x 6"(W) x 4" (D)
Material	ABS (body), PP (backplate), Polyoxymethylene (hammer) polycarbonate (window)

The above data is typical of normal production and should not be taken as a specification.

Product	Pack size	Product code	
IntelliCare™ Manual Dispenser - Black	6 dispensers / carton	D1224700	
IntelliCare™ Manual Dispenser - White	6 dispensers / carton	D1224701	

Medguard Professional Healthcare

Tel: 01 835 2378

Email: [orders@medguard.ie](mailto:orders@medguard.ie)

Fax: 01 969 5009

Web: [www.medguard.ie](http://www.medguard.ie)

Unit 6/7, Block 4, Ashbourne Business Park, Ashbourne, Co. Meath, Ireland