

4.2m (14ft) Tail Call Lead

Part No. **NC805C/14**



Overview

- A long 4.2m tail call lead for use with C-TEC's Quantec and 800 Series Call Systems.
- Allows users to remotely generate Standard calls from armchairs, beds, etc.
- Comprises a pear-shaped call push, 4.2m (14ft) trailing lead and a 6.35mm remote jack plug.
- Easily connects to the 6.35mm remote socket on compatible Quantec and 800 Series call points.
- Activating the pear push or removing the tail call lead from a call point's remote socket will generate a Standard call.



More Information

Technical Specifications

Compatibility	C-TEC's Quantec and 800 Series Call Systems.
Quiescent current	0mA (none).
Alarm current	Determined by the type of control equipment and number / type of field devices connected to the system.
Indicators	Reassurance LED on host call point will illuminate steady when call push is activated and/or removed.
Controls	Red Call button (generates a Standard call on activation when connected to a compatible Quantec or 800 Series call point).
Connections	6.35mm (quarter inch) jack plug.
Onboard Sounder	No,
Onboard Infrared Receiver	No.
Product dimensions (mm)	26 W x 21 H x 74 D mm (pear push). Lead is 4.2m (14ft) long.
Construction & finish	Plastic.
IP Rating	IP40.
Weight	118g
Operating conditions/temperature	-5°C to +40°C. Max. relative humidity 95% non-condensing.